



ACCURIST

LONDON

Troubleshooting

IA06

The analogue hands block the digital display.

1. Press and hold the 'UL' button for 3 seconds. The hour and minute hands will retract to the 12 O'clock position.
2. Press the 'UL' button again to return the hour and minute hands to the previous position.

The analogue time does not match the digital time for the selected time zone.

1. Push the 'LR' button until the mode hand indicator points to TME.
2. Select the time zone on the digital display by pressing 'UR' or 'LL' buttons.
3. Press 'UR' and 'LL' buttons simultaneously and release. The hour and minute hand will go to the time zone shown on the digital display. At this point the digital display may show UTC or another time zone. Press 'UR' or 'LL' buttons to scroll back to the desired time zone.

The analogue hands are not precisely synchronised with the digital time.

1. Press 'LR' button until the mode hand indicator points to CHR.
2. Pull 'LR' button out to first click. The hour, minute and UTC hands will retract to the 12 O'clock position. UTC will be shown in the top half of the digital display.

The analogue hands are not precisely synchronised with the digital time (continued).

3. Press 'UR' button to advance the hands to the straight up 24 hour position. Use 'LL' button to go in reverse.
4. Press 'UL' button, this will show HR in the top half of the digital display. Press 'UR' button to move clockwise or 'LL' button to move anti-clockwise until the hour and 24-hour hands both point straight up.
5. Press 'UL' button to show MIN in the top half of the digital display. Press 'UR' or 'LL' buttons until the minute hand points straight up.
6. Push 'LR' button back in to the starting position.

The watch malfunctions in some way and the previous procedures do not work.

1. Press the 'LR' button until the mode hand indicator points to TME.
2. Pull 'LR' button out to first click. Press 'UL', 'LL' and 'UR' buttons simultaneously and release to reset your watch. 8's will be shown on the digital display.
3. Press 'UL' button. UTC will be shown in the top half of the digital display. Press 'UR' button to advance the hands of the top dial to the straight up 24 hour position. Use 'LL' button to go in reverse.

**** Troubleshooting continued overleaf.***

The watch malfunctions in some way and the previous procedures do not work (continued).

4. Press 'UL' button. HR will be shown in the top half of the digital display. Press 'UR' button to move clockwise or 'LL' button to move anti-clockwise until the hour and 24 hour hand are both in the straight up position.
5. Press 'UL' button. MIN will be shown in the top half of the digital display. Press 'UR' button to move clockwise or 'LL' button to move anti-clockwise until the minute hand is pointing straight up at the 12 O'clock position.
6. Push the 'LR' button back in to the starting position.

If you require further technical assistance contact:

Accurist service centre:

Alexander House

Chartwell Drive

Wigston

Leicester

LE18 2EZ

T: +44 (0) 116 288 2500

E: service@accurist.co.uk