

Service and Repairs

Your ACCURIST watch is guaranteed against defects in materials and workmanship for a period of 2 years from the date of purchase. During this period, we will exchange or repair, at our discretion, any defective components free of charge.

IMPORTANT - Not covered by Guarantee

1. Batteries, straps and bracelets.
2. Damage caused by accident, misuse or lack of care.
3. Water penetrations except in watches marked as "Water Resistant".

SERVICING AND REPAIRS UNDER GUARANTEE

Please post your watch, together with the Retailer's Sales Receipt or proof of purchase, the completed Guarantee slip, and a brief note to explain the nature of the fault, by Registered Post or Recorded Delivery to the address shown. Do not send the presentation box as this will NOT be returned.

SERVICING AND REPAIRS OUTSIDE OF GUARANTEE

Available at a reasonable charge after an estimate has been sent by T.P. (UK) Ltd. Send your watch to us by Registered Post or Recorded Delivery to the address shown.

Important Note

It is important to identify your watch correctly. If, after reading this Instruction Guide, you have any further questions regarding the use, operation or adjustment of your watch, please call us during office hours on 0116 288 2500.

T.P. (UK) Ltd, Alexander House, Chartwell Drive, Wigston, Leicester
LE18 2EZ
United Kingdom.

Water Resistance

If your watch is water resistant, it will clearly state "Water Resistant" or have a static water pressure indication (e.g. "30/50/100/200 metres") on the dial and/or case back.

If it is not marked as water resistant, it should not be allowed to come into contact with water or be worn in conditions that could expose it to moisture (e.g. washing, heavy rain etc.). Certain chemicals in water may damage the watch seals. To maintain water resistance, we recommend that your watch is serviced and re-sealed at least every 12 months by T.P. (UK) Ltd.

IMPORTANT

Buttons must not be operated while in contact with water.

WATER RESISTANT or RESISTANT TO 30 METRES

Suitable for normal everyday use and will resist exposure to splashes and rain; it is NOT designed to be used whilst bathing or swimming.

WATER RESISTANT TO 50 METRES

As 30 metres plus bathing or swimming.

WATER RESISTANT TO 100 METRES

As 50 metres plus pool side diving and snorkelling, but not high board or scuba diving.

WATER RESISTANT TO 200 METRES

As 100 metres plus scuba diving, but not high board diving.



Button and display key

Upper Left button 'UL' (hold) is for retracting hands to 12 O'clock position.

Lower Left button 'LL' is for adjustments **DOWN** when altering settings.


Lower Right button 'LR' is for function change.

Upper Right button 'UR' is for adjustments **UP** when altering settings.

Dial 'A' is UTC time indicator = GMT.

Dial 'B' is 24 hour indicator.

Dial 'C' is function choice indicator.



Digital Display D

When in Time mode: TME

D1: Name of City, e.g. LON (London)

D2: Time in City (hours)

D3: Time in City (minutes)

D4: AM or PM

D5: Summer time indicator

D6: Seconds

Display E & F

The exact function each button performs is displayed in the small display panels E & F, they change dependant on which mode the watch is in.

E1 corresponds to UR button.

E2 corresponds to LR button.

F1 corresponds to UL button

F2 corresponds to LL button

Instructions

If the hands are obscuring the digital display, press and hold 'UL' button to retract the hands to the 12 O'clock position at any time.

Features

- 30 Time Zones
- 3 Alarms
- Calender
- Chronograph
- Countdown Timer

Setting the time

1. Press 'LR' button until the mode hand indicator points to TME.
2. Select the time zone on the digital display by pressing 'UR' to increase the number or 'LL' to decrease the number.
3. Pull out 'LR' to first click. When the lower part of the digital display is flashing press 'LL' to select or deselect summer time.
4. Press 'UR' to flash the seconds, press 'LL' to reset to 00.
5. Press 'UR' to flash the minutes, then press 'LL' to select the current time.
6. Press 'UR' to flash the hours, then press 'LL' to select the current time.
7. Press 'UR' to flash 12H or 24H. Press 'LL' to switch between 12 hour and 24 hour.
8. Once this sequence is complete push 'LR' back in to starting position to confirm selections.

** Instructions continued overleaf.*

GUARANTEE

PLEASE USE BLOCK CAPITALS

NAME

ADDRESS

POST CODE

DAYTIME TELEPHONE NUMBER

IMPORTANT

This guarantee slip should be retained by the owner of the product and should be sent to Timeproducts (UK) Ltd. together with the product and £12 to cover the handling and postage when service under Guarantee is required.



GUARANTEE

DATE OF PURCHASE:

Retailers stamp if required or full name and address:

Please attach the receipt or proof of purchase; failure to attach these may invalidate this Guarantee.

This Guarantee does not affect your statutory rights.

IA06/06-2015

Instructions

Setting the time zone

* *Setting the time zones allows you to add or remove cities or switch between daylight saving and standard time.*

1. Press 'LR' until the mode hand indicator points to SET.
2. Pull out 'LR' to first click. When the digital display is flashing press 'UL' to select either SET to display the city, or OFF to not display the city.
3. Press 'UR' to scroll through the different cities.
4. Press 'LL' to select summer time either on or off.
5. To confirm the settings push 'LR' back to starting position.

Setting the calender

1. Press 'LR' until the mode hand indicator points to CAL.
2. Select the time zone by pressing 'LL' or 'UR'.
3. Pull out 'LR' to first click, the month will now be selected and flashing in the digital display.
4. Press 'LL' to increase the number.
5. Press 'UR' to select the date, the date will now be flashing. Then press 'LL' to increase the number.
6. Press 'UR' to select the year, the year will now be flashing. Then press 'LL' to increase the number to the current year.

Instructions

Setting the calender (continued)

7. Once the above steps are complete, push 'LR' back in to the starting position to confirm the settings.

Setting the alarms

1. Press 'LR' until the mode hand indicator points to either AL1, AL2 or AL3.
2. Select the time zone by pressing 'LL' or 'UR'.
3. Pull out 'LR' to first click, ON or OF will now be flashing in the digital display. Press 'LL' to switch between selections.
4. Press 'UR' to select the hours and press 'LL' to increase the number.
5. Press 'UR' to select the minutes and press 'LL' to increase the number.
6. Push 'LR' in to starting position to confirm selections and set the alarm.

Instructions

Using the Chronograph

1. Press 'LR' until the mode hand indicator points to CHR.
2. Press 'UR' to start and stop the chronograph timing.
3. Press 'LL' whilst the chronograph is running to display the split time for 10 seconds.
4. When the chronograph is stopped, press 'LL' to reset to zero.

Using the countdown timer

1. Press 'LR' until the mode hand indicator points to TMR.
2. Pull out 'LR' to the first click, the minutes will be flashing in the digital display. Press 'LL' to change the number.
3. Once the minutes on the timer have been set, push 'LR' in to starting position to confirm the settings.
4. Press 'UR' to start and stop the countdown timer.
5. When stopped, press 'LL' to reset the countdown timer to its initial preset time.

* *Please note the value range for the countdown timer is 1 minute to 60 minutes.*

World Time Zone Reference Table

City Code	City	Country	Time Difference
UTC	Coordinated Universal Time	N/A	N/A
LON	London	UK	±00:00 UTC
PAR	Paris	France	+01:00 UTC
ROM	Rome	Italy	+01:00 UTC
CAI	Cairo	Egypt	+02:00 UTC
IST	Istanbul	Turkey	+02:00 UTC
MOW	Moscow	Russia	+02:00 UTC
KWI	Kuwait	Kuwait	+02:00 UTC
DXB	Dubai	UAE	+04:00 UTC
KHI	Karachi	Pakistan	+05:00 UTC
DEL	New Delhi	India	+05:30 UTC
DAC	Dhaka	Bangladesh	+06:00 UTC
BKK	Bangkok	Thailand	+07:00 UTC
SIN	Singapore	Singapore	+08:00 UTC
HKG	Hong Kong	China	+08:00 UTC
PEK	Peking (Beijing)	China	+08:00 UTC

World Time Zone Reference Table

City Code	City	Country	Time Difference
TYO	Tokyo	Japan	+09:00 UTC
SYD	Sydney	Australia	+10:00 UTC
NOU	Noumea	New Caledonia	+11:00 UTC
AKL	Auckland	New Zealand	+12:00 UTC
HNL	Honolulu	USA	-10:00 UTC
ANC	Anchorage	USA	-09:00 UTC
LAX	Los Angeles	USA	-08:00 UTC
DEN	Denver	USA	-07:00 UTC
CHI	Chicago	USA	-06:00 UTC
MEX	Mexico City	Mexico	-06:00 UTC
NYC	New York	USA	-05:00 UTC
YUL	Montreal	Canada	-05:00 UTC
CCS	Caracas	Venezuela	-04:00 UTC
RIO	Rio de Janeiro	Brazil	-03:00 UTC
BUE	Buenos Aires	Argentina	-03:00 UTC